

iPega Gamepad Direct-Play Mode Default Setting on iOS/Android devices

Direct-Play Mode Default Setting on iOS/Android devices

iOS devices: Press and hold "Y+HOME" buttons on

iPega gamepad, Open bluetooth on your devices,

Search "Gamepad Model" Connect it

Android devices: Press and hold "A+HOME" buttons

on iPega gamepad, Open bluetooth on your devices,

Search "Gamepad Model" Connect it

Change preset game by press buttons on the gamepad:HOME+UP : PUBG Mobile;HOME+RIGHT : Arena of ValorHOME+DOWN : Mobile Legends;HOME+LEFT : Knives Out

0	N 🔶 D	12:05 م
BT		
On		2
Paired	devices	
Ω	SONY NW-ZX100	\$
Ω	SONY SRS-X77	\$
0	SONY SmartWatch 2	\$
	SONY XPERIA Z2 Tablet	\$
Availab	le devices	
M	PG-9118	

Direct-Play Mode Default Setting on iOS/Android devices

Default game buttons for **PUBG Mobile &**

Knives Out as shown

Remarks:

When using this product, please placed the device horizontally. And make sure the HOME key is on the right. Restore the game's buttons to their default settings. Please find the steps shown at **next page**

Change preset game by press buttons on the gamepad: HOME+UP : PUBG Mobile; HOME+RIGHT : Arena of Valor

HOME+DOWN : Mobile Legends;

HOME+LEFT : Knives Out

No#	Controller buttons	PUBG	No#	Controller buttons	PUBG	
	Single key	POBG		Single/Cabination key	FUBG	
1	Α	Jump	13	R1+A	Bag	
2	В	Squat	14	R1+Y	Run 📕	
3	x	Lay down	15	R1+L2	Get in	
4	Y	Мар	16	R1+R2	Bullets reload	
5	D-pad UP	Pick up equipment	17	R2	Fire	
6	D-pad Down	Revive Open door	18	R3	Grenade	
7	D-pad Left	Main Weapon	19	Right Joystick	Angle view	
8	D-pad Right	Secondary Weapon	20	L1 +Right Joystick	View	
9	R1+D-pad Left	Turn left	21	L2	Aim	
10	R1+D-pad Right	Turn right	22	L3	Medicine	
11	R1+ D-pad Up	Drive Orive	23	Left Joystick	Move	
12	R1+ D-pad Down	Get off				

Direct-Play Mode Default Setting on iOS/Android devices

* If you changed the game buttons before, please Reset the game buttons

Step1 Open "Setting" in the game, enter "Customize" interface

Step2 Click "Reset", Save it and Exit



Change preset game by press buttons on the gamepad:HOME+UP : PUBG Mobile;HOME+RIGHT : Arena of ValorHOME+DOWN : Mobile Legends;HOME+LEFT : Knives Out



Arena of Valor & Mobile Legends default game buttons as shown below:

Game Action	Gamepad	Game Action	Gamepad	Notes
Moving direction	Left joystick	TP	R1+L1	
Purchase equipment up	D-pad ↑	Recover	R1+L2	
Purchase equipment down	D-pad ↓	Summoner Spells	R1+R2	
Add skills 1	D-pad ←	Мар	Right joystick	
Add skills 2	D -pad \rightarrow	Attack	R1+X	
Add skills 3	R3	Retreat	R1+Y	
Normal attack	A	Gather	R1+B	
Topple towers	В	Open the shop	R1+D-pad ↑	
Add knife	Х	Pick up objects	R1+D-pad ←	Border Chicken
Against information	Y	Salve	R1+A	games mode
Skill 1	L1	Backpack	R1+D-pad ↓	
Skill 2	L2	Мар	R1+D-pad \rightarrow	
Skill 3	R2			

Change preset game by press buttons on the gamepad:

HOME+UP : PUBG Mobile;HOME+RIGHT : Arena of ValorHOME+DOWN : Mobile Legends;HOME+LEFT : Knives Out



How to reset game buttons using ShootingPlus V3 APP On iOS devices

Youtube guide video: https://www.youtube.com/watch?v=DeQQ0DPdtHQ

How to Use ShootingPlus V3 APP on iOS devices

Step1 Download and install "ShootingPlus V3 " APP from APP store Step 2 Open "ShootingPlus" APP, You can see that there are a lot of games that have preset buttons, which can be downloaded to gamepad. After download, Click "V3" popup window, "Choose" the game buttons in the app or press the buttons on the gamepad to change game buttons.





How to Use ShootingPlus V3 APP on iOS devices

If you want to set the game buttons follow your habits, please check the steps as shown below:

Step1 Get a Screenshot from the game

(For PUBG, Click "Setting" ----- "Control",

Enter "Customize" interface)



Step2 Open Shootingplus App, Click "V3" popup window, **Long press** the blank area, Load the screenshot for game buttons





How to Use ShootingPlus V3 APP on iOS devices

Step 3 Click "NEW", all of the game buttons will be clear, and press the button on the gamepad and drag them to right position, after all game buttons are set, save and exit.



Step 4 Open the game, enjoy it !



How to reset game buttons using ShootingPlus V3 APP On Android devices

Youtube guide video: https://www.youtube.com/watch?v=DeQQ0DPdtHQ

Step1 Download and install "ShootingPlus V3 " APP from Google Play Store,

How to Use ShootingPlus V3 APP on Android devices

Open "ShootingPlus" APP, Enable the floating window, Permit drawing over other apps



Step 2 You can see that there are a lot of games that have preset buttons, which can be

downloaded to gamepad. After download, Click "V3" popup window, "Choose" the game buttons

in the app or press the buttons on the gamepad to change game buttons.





OQO[®] How to Use ShootingPlus V3 APP on Android devices

If you want to set the game buttons follow your habits, please check the steps as shown below:

Step1 Open the game, click "V3" popup window, "Choose" the Prset game buttons in the app





How to Use ShootingPlus V3 APP on Android devices

Step 2 If you want to set all buttons follow your habit, Click "NEW", all of the game buttons will be clear, and press the button on the gamepad and drag them to right position, after all game buttons are set, save and exit.

Step 3 Open the game, press "SELECT" on the gamepad, game buttons will appear, enjoy the game!



